

Caution !**Please process E-cleaning every 1~2 weeks**

- The machine must keep power on during process the E-cleaning.
- Please use one pack of cleaning powder which fabricated by Enagic only.



1. Open the cap of Cleaning powder unit(CPU), pour the cleaning powder inside and tight it back.



2. Open the machine black cover and remove the internal filter. Replace the filter with the CPU



3. Press the Purified Water(Green) button for 10 seconds then switch off.



4. Place both the white flexible hose and the white secondary hose in a cup then leave for 3 to 5 hours



5. Remove the cup and press the clean water again for 10 minutes.



6. Install the filter back and press the clean water again for 3 minutes.



7. Install the black cover and the E-cleaning completed. E-cleaning can clean the electrode plate of Kangen water, electrode plate of strong acid water cleaned by pressing the cleaning button on machine or electric pump only.

- ※ After the E-cleaning, there may be sediments found in the water, please abandon if any sediments found.
- ※ Please use water to clean the CPU after use, make it dry and keep it safe.
- ※ If there is damage on the O-ring of CPU, don't use it. CPU should be changed every 3 years.